

SPECIFICATION & DATA SHEET

ZONE SERVICE UNIT (ZSU)

The MIPS Zone Service Unit (ZSU) is designed for aesthetics, economy, reliability and durability, whilst requiring minimum maintenance. They are available as a standard product with the following features:

- Complies fully with the requirements of HTM 02-01
- Available in both surface and part-recessed format
- Standard colour is white
- Fully removable, hinged cover for easy fitting and maintenance
- All valves fitted with BS 5682 NIST connectors
- All valves fitted with flat-faced 'o' ring unions
- Standard pipework sizes 15-28mm
- Each valve supplied with blanking facility
- Every ZSU is pressure tested prior to despatch
- Every ZSU electrically tested prior to despatch
- Every valve is tested for tightness (no pressure pass when closed)
- Includes all internal pipework and stubbed connections outside the enclosure for easy fitting
- Pipework soldered using Inert Gas Jointing Procedure
- Alarm panel Shire Controls type SA6
- Pressure sensors fitted with minimum leak facility



In addition to all of the above, MIPS can offer the following options:

- Floor-to-ceiling enclosures
- Other colours are available
- 35-42mm pipework valves

The right is reserved to change the specification of the items described herein at any time.